

# DEPARTMENT OF NATURAL RESOURCES

04/02/2012

# **BID PROPOSAL**

431-2003-PA12-006

# ABANDONMENT OF OILFIELD SITES

# Big Creek and Monroe Fields

Sections 035 and 036, Township 20N, Range 05E; Sections 1, 2, 24, and 25, Township 19N, Range 05E; Section 31, Township 20N, Range 06E; and Sections 5 and 8, Township 16N, Range 08E in

# Morehouse and Richland Parishes

Bid Opening Date: 05/08/2012

# **NOTICE TO BIDDERS**

Sealed bids will be opened and publicly read by the Department of Natural Resources, 617 North 3rd Street, 12th Floor, Room 1263, Baton Rouge, Louisiana at 11:00 A.M. on May 8, 2012 for the following:

# Bid Proposal Number: 431-2003-PA12-006

**Title:** Sections 035 and 036, Township 20N, Range 05E; Sections 1, 2, 24, and 25, Township 19N,Range 05E; Section 31, Township 20N, Range 06E; and Sections 5 and 8, Township 16N, Range 08E in Richland and Morehouse Parishes, and are subject to the jurisdiction of the Monroe District Office.

NOTE: A one-time <u>MANDATORY SITE VISIT</u> will be held on Monday, April 23, 2012. Preregistration is required. To pre-register, contact Jackie Devall @ 318-362-3111 by 12:00 P.M., April 20, 2012.

This signed statement certifies that the Co familiar with all conditions surrounding fu Failure to complete or return this certificat	alfillment of the requirements for this project.	
Company Name (Contractor)	Signature (Contractors Representative)	
Department of Natural Resources		
Agency Name	Signature (Agency Representative)	

This bid is being solicited under the provisions of the Louisiana Oil Field Site Restoration Law (Act 404 of 1993). Only bidders on the approved list of contractors (referenced in Act 404) at time of first public notice of solicitation shall be considered.

Bidder agrees bid shall be good for a period of sixty (60) calendar days of the bid opening.

The successful bidder (contractor) will be required to execute a performance bond or deliver a letter of credit in the full amount of the contract.

Bidder must return entire bid proposal package with signature pages and with exceptions noted. Bidders must use the specified forms available in the bid proposal package. Bids must be filled out with ink or typewritten and signed in ink. Any alteration, erasure or correction must be initialed by signer of the bid, failure to do so may cause your bid to be rejected.

Bid must be returned in Special Bid Envelope. Bidder is to include company name and complete return address on the outside of bid envelope. In the event of bulky material, the Special Bid Envelope must be firmly affixed to the mailing envelope.

BIDS MUST BE HAND DELIVERED WITH RECEIPT GIVEN OR SENT BY REGISTERED OR CERTIFIED MAIL (WITH RETURN RECEIPT). BIDDER SHALL ASSUME FULL RESPONSIBILITY FOR TIMELY DELIVERY TO THE LOCATION DESIGNATED ON THE BID RETURN ENVELOPE FOR RECEIPT OF BIDS.

PROPOSAL NUMBER: 431-2003-PA12-006 BID OPENING DATE: May 8, 2012

Dept. of Natural Resources **Purchasing Section** 617 N. 3rd St., 12th Floor, Room 1263 Baton Rouge Louisiana 70802

PROJECT: Furnish all labor, materials, tools and equipment necessary for the Project as per plans, drawings and specifications prepared by the agency.

The undersigned, in compliance with your invitation for bids for the project listed above, having examined the specifications and related documents, inspected site and being familiar with all of the conditions surrounding the fulfillment of the contract, hereby proposes to furnish all labor, materials, tools and equipment necessary to complete the above referenced project within the time set forth herein and for the price stated below.

The Lump Sum Total Price stated shall include all permits and governmental fees, licenses, and inspections, and all sales, consumer use and taxes of any other nature or kind whatever arising from or pertaining to the work or portions thereof provided by the contractor which are legally enacted at the time bids are received. whether or not yet effective.

**BASE BID:** I/We propose to furnish all materials and perform all work as described in the specifications and related documents for the sum of:

LUMP SUM	TOTAL \$
	(WORDS AND FIGURES)
	See: (Enclosed Page for BREAKDOWN OF LUMP SUM TOTAL)
COMPLETIO	ON DATE: The undersigned guarantees completion of project as per base bid incalendar days.
	re so indicated by the makeup of the bid form, sums shall be expressed in both word gures, and in case of a discrepancy between the two the written amount shall gover
	LOUISIANA CONTRACTORS' LICENSE NO
	NAME (PRINT OR TYPE)
	TITLE (PRINT OR TYPE)
	SIGNATURE
	FIRM NAME ADDRESS (Roy)
	ADDRESS (Box)
	(Physical)
	CITY, STATE, ZIP
	PHONE ( ) FAX ( ) E-MAIL

It is not necessary to return "NO-BID" packages for Plug & Abandon Bids.

IMPORTANT: IN ACCORDANCE WITH R.S. 37:2163A CONTRACTORS' LICENSE NUMBER MUST APPEAR ON THE BID OPENING ENVELOPE ON ALL PROJECTS IN THE AMOUNT OF \$50,000.00 OR MORE (AND \$1.00 OR MORE IF HAZARDOUS MATERIALS ARE INVOLVED). ALL BIDS NOT IN COMPLIANCE WITH THIS REQUIREMENT SHALL BE AUTOMATICALLY REJECTED AND NOT READ. FOR ANY BID SUBMITTED IN THE AMOUNT OF FIFTY THOUSAND DOLLARS OR MORE, THE CONTRACTOR SHALL CERTIFY THAT HE IS LICENSED AND SHOW HIS LICENSE NUMBER ON THE BID. (Bids must be submitted under the name which the La. State Licensing Board for Contractors has issued the contractor's license. Do not submit under dba names).

Bid proposal form, information and specifications may be obtained from the Purchasing Section, Dept. of Natural Resources, P.O. Box 44362 (or 617 N. 3rd Street, 12th floor, Room 1263), Baton Rouge, LA 70804, or by calling 225/342-4535 or 225/342-6397.

No bids will be received after the date and hour specified. The right is reserved to reject any and all bids and to waive any informalities.

Bidders may attend the bid opening, but no information or opinions concerning the ultimate contract award will be given at the bid opening or during the evaluation process. Bids may be examined after 72 hours of the bid opening. Information pertaining to completed files may be secured by visiting the Dept. of Natural Resources during normal working hours. Written bid tabulations will not be furnished unless requested.

**NOTE:** INCLUDE COMPLETE FIRM NAME AND RETURN ADDRESS ON THE BID RETURN ENVELOPE.

**SIGNATURE AUTHORITY:** In accordance with L.R.S. 39:1594 (Act 121), the person signing the bid must be:

- 1. A current corporate officer, partnership member or other individual specifically authorized to submit a bid as reflected in the appropriate records on file with the Secretary of State; or
- 2. An individual authorized to bind the vendor as reflected by an accompanying corporate resolution, certificate or affidavit; or
- 3. An individual listed on the State of Louisiana Bidder=s Application as authorized to execute bids.

By signing the bid, the bidder certifies compliance with the above.

# GENERAL CONDITIONS, INSTRUCTIONS, POLICIES AND PROCEDURES

**ADDENDA:** The contractor must attach all addenda to his bid or otherwise acknowledge the receipt of same.

WITHDRAWAL OF BIDS: The contractor agrees that this bid shall be good and may not be withdrawn for a period of sixty (60) calendar days after the bid opening.

**AFFIDAVIT**: Successful contractor shall be required to execute an affidavit attesting "THAT PUBLIC CONTRACT WAS NOT SECURED THROUGH EMPLOYMENT OR PAYMENT OF SOLICITOR" in compliance with Title 38, Section 2224.

# **CONTRACT, FINANCIAL ASSURANCE:**

If the undersigned is notified of the acceptance of the above bid or bids, within thirty (30) days of the time set forth for the opening of bids, he agrees to execute a contract for the work accepted within ten (10) days after notice from the Dept. of Natural Resources.

The undersigned further agrees, if awarded the contract, either to execute and deliver to the Dept. of Natural Resources prior to execution of contract, a Performance Bond with Power of Attorney or to deliver a Letter of Credit in an amount equal to 100% of the contract amount, all as outlined in Attachment AA@.

In addition, to be provided at the same time is a labor and materials bond or a letter of credit in an amount equal to 100% of the contract amount, all as outlined in the Attachment AA@.

**RECORDATION CERTIFICATE:** Contractor shall upon receipt of executed contract, financial assurance documents and purchase order, record contract and financial assurance documents with the Clerk of Court in the parish in which the work is to be performed, obtain a Certificate of Recordation from the Clerk of Court and forward this Certificate immediately to the Department of Natural Resources. This certificate must be received before any invoices on this project can be processed. The expense for this is the responsibility of the contractor.

**PAYMENT:** Upon satisfactory completion of the work, ninety percent (90%) of the Contract Price shall be paid to contractor.

**ACCEPTANCE:** Upon completion of the work to the satisfaction of the Dept. of Natural Resources, a Notice of Acceptance of Work will be executed by the Dept. of Natural Resources and forwarded to the contractor for recording with the Clerk of Court in the parish in which the work has been performed. Contractor shall furnish to the Dept. of Natural Resources a Clear Lien Certificate from the Clerk of Court (to the owner along with final invoice) forty-five (45) days after recordation of acceptance. Upon receipt, final payment of ten percent (10%) of the Contract Price will be made.

**NON-DISCRIMINATION:** The Dept. of Natural Resources does not discriminate on the basis of race, color, national origin, sex, disability, age, or sexual orientation; and requires its contractors, subcontractors, and suppliers to comply with this commitment.

**MINORITY/WOMAN OWNED:** If your organization is a Minority or Woman-Owned Enterprise, please send supporting documentation. This information is required for the purpose of reporting to Federal Funding Agencies. Send info. to: Dept. of Natural Resources, Purchasing Section, Attn: Judy LeBourgeois, PO Box 44362, Baton Rouge, LA 70804-4362 or e-mail: Judy.lebourgeois@la.gov

# **INDEX**

# **Sections**

Section 1 Introduction Section 2 Instructions for Bidders/Contractors Change Order Procedures Section 3 Section 4 Definitions Information Bidders are Required to Submit Section 5 Minimum Equipment Requirements Section 6 Scope of Work Section 7 Section 8 Breakdown of Lump Sum Total

# **Attachments**

Attachment 'A' Financial Assurance Requirements

Attachment 'B' Insurance Requirements

Attachment 'C' NORM Survey Results

# Section 1 INTRODUCTION

The Louisiana Department of Natural Resources (LDNR) needs eighteen (18) orphan wells in the Big Creek and Monroe Fields plugged and abandoned. These sites are located in: Sections 035 and 036, Township 20N, Range 05E; Sections 1, 2, 24, and 25, Township 19N, Range 05E; Section 31, Township 20N, Range 06E; and Sections 5 and 8, Township 16N, Range 08E in Richland and Morehouse Parishes, and are subject to jurisdiction of the Monroe District Office.

Enclosed in this bid document are instructions to the bidders and other information pertaining to these sites.

# Section 2

# **INSTRUCTIONS FOR BIDDERS/CONTRACTORS**

- 1. The bid price shall be submitted as a **LUMP SUM** quote for the complete scope of work including, but not limited to:
- Management / Supervision
- Personnel
- Equipment
- Engineering
- Mobilization and demobilization
- Logistics relating to personnel, equipment, or any other costs associated with support services
- Materials and supplies
- Weather and local interference
- 2. Bidders are to note that their lump sum bid shall be inclusive of any and all qualifications, clarifications, and/or exceptions the bidder may have. Any qualifications, clarifications, or exceptions may disqualify the bid.
- 3. All third party services utilized, equipment rented, or expendables used shall be paid directly by the contractor and included in the contractor's lump sum bid price.
- 4. Bidders shall take into account all salvage value on any equipment in their lump sum bid price. Additionally, bidders shall separately identify and place a value on each piece of salvage equipment on a well by well basis. The Department of Natural Resources will only assume the recovery of that surface equipment present on the site at the time of the site visit. Casing and tubing documented for each well in Section 6 under the heading of General Information will be assumed to be present but not guaranteed recoverable or saleable, therefore no value should be attributed to it. Any bidder who places a salvage value on such tubulars shall be solely responsible for recovery and merchantability thereof. The recovery of casing, tubing, pumps, sucker rods, packers, tubing hangers, and other downhole equipment is not warranted. All attempts to retrieve casing from the well must be done in accordance with the requirements contained in Item No. 26 of this Section. NOTE: The contractor shall dispose of all salvaged equipment.
- 5. If a lienor requests a hearing, and it is there determined that the salvage value exceeds the cost to restore the site, LDNR reserves the right to cancel any contract under which it does not receive from the contractor adequate funds to be paid to such lienor.
- 6. Bidders shall submit the name, address, phone number, Federal Tax ID number, and a description of the nature of the work for each proposed subcontractor.
- 7. **LDNR does not have a contractual relationship with any subcontractors**. LDNR is not obligated to pay or see that a subcontractor is paid for the work he performs. The contractor is responsible for their subcontractors acts or omissions.

- 8. Bidders are notified that no explosives shall be allowed while carrying out the scope of work, with the exception of down hole perforating or down hole tubular cutting requirements.
- 9. Bidders shall submit their detailed proposed procedures to carry out the scope of work contained in this bid document. Failure to do so may result in the bid being rejected.
- 10. Contractor is responsible for all mobilization and demobilization of personnel, equipment, materials, and supplies.
- 11. The contractor shall be responsible for the planning and execution of all site restoration and removals described in the scope of work.
- 12. The contractor shall be responsible for making their representatives and subcontractors familiar with the site conditions within the scope of work.
- 13. The contractor shall be responsible for **removing**, **testing**, **transporting**, **and disposing** of all hazardous and nonhazardous **oilfield waste**, equipment, and scope of work materials in a manner that complies with all federal, state, and local regulations.
- 14. The contractor shall at all times keep the premises free from accumulations of waste materials and debris. If any materials are determined to be hazardous, removal and proper disposal according to the Department of Environmental Quality standards is the responsibility of the contractor.
- 15. Prior to commencement of work, the successful bidder shall either execute and deliver a **performance bond** or deliver a **letter of credit** as exhibited in **Attachment 'A'**. The Financial Assurance Document shall reference the bid proposal number.
- 16. No work outside the scope of the bid award may be performed unless approved by Change Order. See Section 3 for change order procedures.
- 17. **Prior to commencement of work**, the successful bidder shall obtain all applicable work permits to perform the scope of work from the appropriate District Office. **The successful bidder shall notify the appropriate District Office in writing at least 24 hours prior to commencement of work.** Failure to notify the District Office shall result in a \$500.00 penalty to the successful bidder.
- 18. The contractor shall be responsible for notifying the site landowners and/or lease holders and the landowners and/or lease holders of any property used for ingress and egress prior to the commencement of work. You must fill out the landowner affidavit form that will be provided with the contracts when a bid is awarded. The forms must be sent to the district with final paperwork once a job is complete (This may not always be possible, but a good faith effort must be made). The contractor shall notify the landowners at least 24 hours prior to commencement of work; however, acquisition of rights-of-way is unnecessary because the Act authorizes entry on land of another by the Secretary or his agents for site assessment or restoration.
- 19. If the contractor **fails to commence work** within the time specified in the "Notice to Proceed", the contractor may either be assessed a penalty of ½ % of the contract amount for each day work has not commenced or the bid will be awarded to the next low bidder. This will be at the discretion of LDNR. The dollar amount of the penalty shall be deducted from the 90% payment once the project is complete.
- 20. Once the work commences, there shall not be more than a 24 hour lapse in work without the written consent of the Commissioner of Conservation; with the exception of Saturdays and Sundays if the contractor does not plan to work weekends. If an unauthorized lapse of 24 hours or more occurs, the contractor shall be assessed a penalty of ½ % of the contract amount for each day work is not being performed. The dollar amount of the penalty shall be deducted from the 90% payment once the project is complete.

- 21. **Unless an extension is authorized** by the Commissioner of Conservation, if a contractor **fails to complete** the project by the completion date stated in the "Notice to Proceed", the contractor shall be assessed a penalty of ½ % of the contract amount for each day beyond the completion date until the job is satisfactorily completed. The dollar amount of the penalty shall be deducted from the 90% payment once the project is complete.
- 22. Once the project has begun, the **contractor shall be responsible for submitting a daily report** on all work performed. These reports shall be submitted **to both the Baton Rouge and appropriate District Office by fax each morning** by 9:00 AM for the work performed the preceding day. A copy of the daily report form to be used will be provided before the job starts.
- 23. All **well plug and abandonments and pit closures** shall be performed in accordance with LAC 43:XIX.Subpart 1 (**Formerly Statewide Order No. 29-B**) and all other federal, state, and local regulations applicable to this work, unless otherwise stated. The bidders are responsible to be aware and knowledgeable of all such regulations and to follow them accordingly. The successful bidder shall be required to obtain all permits from the applicable state and federal regulatory agencies necessary to complete the scope of work for this project.
- 24. All **cement plugs** placed in the wellbore(s) during plugging operations, unless otherwise required in <u>Section 7</u>, shall be blended neat slurries composed of API Class A or H cement, and having a minimum density of 15.6 pounds per gallon. API Class A cement may not be used in plugs placed at depths greater than 6000'. Dry and blended surface samples shall be provided to CES agent if requested.
- 25. All wells, when drilling or running or pulling casing or tubing, shall be equipped with hydraulically operated blow out preventers (BOP) equipped with both blind rams and pipe rams equipped with the proper size elements for the pipe being run. The BOP stack shall also allow full-bore access to the casing below. Unless otherwise stated, the BOP stack shall be rated to a minimum 3,000 psi working pressure.
- 26. **If casing is to be cut and removed** from the wellbore during plug and abandonment activity, a cast iron bridge plug (CIBP) shall be placed inside the casing to be cut, prior to cutting, 100' below the proposed cut depth. After the casing is removed, a bit and scraper run will be made to the top of the cut casing stub. A cement plug shall be placed in the wellbore from the CIBP to a depth 100' above the depth of the cut made on the casing. If the casing immediately inside the surface casing is to be cut, it may not be cut any deeper than a point at least 50' above the shoe of the surface casing.
- 27. <u>Land locations</u>: All production equipment shall be removed and locations shall be restored to natural grade and seeded with grass common to the area. All oil contaminated dirt shall be removed and properly disposed of. Clean replacement or fill dirt (with properly documented analysis for contamination and NORM) shall be brought in to insure location is returned to its natural grade.
- 28. Contractor is responsible for leaving site access ways in equal or better condition than prior to initiation of site restoration activity.
- 29. **Any pit constructed by the contractor** shall be registered with the Office of Conservation, Baton Rouge Office, by submitting a **Form Eng-15** as required by LAC 43:XIX.305.D. Contractor shall be required to close any such pit constructed in accordance with LAC 43:XIX.311 and 313.

- 30. For any pit closed in which the pre-closure soil analysis provided by LDNR does not meet LAC 43:XIX.311 and 313 closure requirements, a confirmatory clean soil sample and a post-closure soil sample shall be taken and analyzed for non-compliant constituent(s). The confirmatory clean soil sample shall be a homogenous, representative sample at the excavated surface. Should the sample analysis exceed the criteria outlined in LAC 43:XIX.311 and 313, excavation shall continue until either no contamination is encountered or the water table is reached. If the water table is reached prior to obtaining a clean sample additional remedial action necessary will be determined via change order. Both analyses shall comply with closure requirements before the project will be accepted and payments made by LDNR. Confirmatory clean soil sample and post-closure soil sample analyses shall also be performed on all production facility containment areas closed and shall also comply with the requirements set forth in LAC 43:XIX.311 and 313. For sampling purposes, pits and facility containment areas are to be divided into a ten square meter grid pattern with representative samples taken from each grid. Subsurface sampling intervals for facilities may be adjusted at a site to accommodate site-specific information on subsurface contaminant distributions and in such cases will be included within the scope of work. Please note that all analytical tests submitted must be performed by Department of Environmental Quality (LDEQ) Louisiana Environmental Laboratory Accreditation Program (LELAP) accredited laboratories. Further, the laboratories must be accredited for each parameter and corresponding method referenced in the Department of Natural Resources (LDNR) lab manual entitled "Laboratory Procedures for Analysis of Exploration & Production Waste".
- 31. Upon completion of the project, contractor shall also file with the Office of Conservation, Baton Rouge Office, Form ENG-16, Oilfield Waste Disposition, indicating the disposition of all waste generated during the site restoration work. Copies of waste shipping manifests are required for all wastes transported off site for disposal.
- 32. It is the responsibility of the contractor while at the site visit to observe the condition of the wellhead and select the means by which entry into the tubing and casing strings can be accomplished. The contractor shall include in the bid price all costs associated with this operation, such as the need for additional valves, hot taps, etc.
- 33. In the event the project becomes lengthy, partial payments will be considered on a case by case basis. The same procedure for final payment will be followed.
- 34. Upon completion of the project, the **contractor shall complete Form P&A** and **Form WH-1** on each well plugged and abandoned and shall file same with the appropriate District Office. Additionally, contractor shall also submit any required pit closure data to the appropriate District Office.
- 35. Bidders may attend the bid opening, but no information or opinions concerning the ultimate contract award will be given at the bid opening or during the evaluation process. Bids may be examined after 72 hours of the bid opening. Information pertaining to completed files may be secured by visiting the Department of Natural Resources during normal working hours. Written bid tabulations will not be furnished unless requested
- 36. **Information in this document** was obtained from Office of Conservation well files and site inspections performed by Office of Conservation personnel; however, because the Office of Conservation does not warrant this information as accurate, bidders are responsible for verifying all well information, pit dimensions, waste volumes, equipment, and other site specific conditions. Bidders shall have the opportunity to gather information by attending a **mandatory site visit** as outlined on Page 2, herein. **Only bidders attending the site visit shall be allowed to bid on this project**. LDNR shall also allow the successful bidder to make prejob inspection trips.

- 37. Should it be determined at any time during site restoration work that a well or site conditions vary significantly from those described in the bid proposal, the LDNR reserves the right to delete the site from the project and compensate the contractor for work performed up to the point the site was omitted from the project. This compensation shall be negotiated in good faith between the contractor and LDNR based upon reasonable industry standards or charges. In the event the price cannot be agreed upon, the Commissioner shall set a fair price for the work and materials at issue and his decision shall be binding upon all parties concerned.
- 38. Contractor agrees to indemnify and hold harmless LDNR from all liabilities and cost of defense obligations resulting from acts of negligence by the Contractor.
- 39. The role of the LDNR personnel during the site restoration work is to ensure that work is being performed in accordance with the approved scope of work. LDNR personnel are not to provide any type of guidance or direction to the contractor or the contractor's subcontractors regarding the routes of ingress or egress to/from the wellsite.
- 40. Contractors shall be responsible to ensure safe operations at all times and shall provide the proper materials, labor and equipment to safely perform the scope of work contained in this bid document. As the job requires, personal protective equipment for hearing, face, head, respiratory protection and fall protection shall be considered for use to protect personnel. Personnel and subcontractors should be properly trained in relation to their job duties. Additionally, pre-job safety meetings that include all affected personnel, including subcontractors, should be held to review responsibilities for the operations to be performed. Suitable fire-extinguishing equipment shall be on site during all operations. Telephone numbers, location, and other relevant information pertaining to availability of medical personnel, transportation, and medical facilities shall be available and a first aid kit shall also be on location. Any unsafe act/practice observed by an agent of the Office of Conservation during scope of work activities may result in the immediate cessation of work activities.
- 41. Any **questions relating to this bid** shall be submitted in writing to Sarah K. Wagner at P.O. Box 94275, Baton Rouge, LA 70804 or fax number 225-342-2584 by 4:30 p.m. five consecutive days after the site visit. No other questions shall be allowed or answered after this time.

#### **CHANGE ORDER PROCEDURES**

A Change Order consists of additions, deletions, or other revisions to the scope of work and may be requested or initiated by the contractor or LDNR. All requests for a Change Order shall be submitted in writing by the Contractor outlining specific factual conditions necessitating issuance of a Change Order. The Change Order shall be a lump sum quote to perform work that deviates from the specific procedures submitted in Item 4(a) of Section 5 necessary to complete the project. The Change Order quote shall include all costs necessary to complete the work covered by the Change Order, including all standby charges incurred during the Change Order approval process. Oral communication shall not be acceptable except in the case of an emergency where the proposed work must be performed immediately. No work relating to the requested Change Order shall be performed without a properly executed Change Order signed by the Contractor and the Commissioner of Conservation or in the event of an emergency verbal authority being granted by the Commissioner.

Except in the event of an emergency, the scope of work and if applicable the price, be it lump sum or time and material with a not to exceed figure, shall be entered on the Change Order form. In the event of an emergency, the contractor shall schedule a meeting with the Commissioner at the earliest possible time to discuss and agree upon a price for this change in work. Once a price is agreed upon, an Emergency Change Order shall be completed and signed by both the Contractor and Commissioner. In the event the price cannot be agreed upon, the Commissioner shall set a fair price for the work and materials at issue and his decision shall be binding upon all parties concerned.

Claims for extra compensation by the Contractor shall not be recognized and shall not be valid unless the Contractor has in his possession prior to the work being performed a properly executed Change Order form giving him the authorization to proceed with the extra work.

# **DEFINITIONS**

- 1. PROCEDURES: A detailed description of the work plan by which the contractor intends to carry out the scope of work.
- 2. LUMP SUM: A firm and inflexible quote that should allow for any unforeseen conditions that may alter or change the projected intent, the like of, but not limited to: procedures, schedules, methods, equipment, personnel, materials, logistics.
- 3. THE WORK: The scope of work described in this bid document and included in the lump sum price.
- 4. CONTRACTOR: The successful bidder of a specific project.
- 5. CONFIRMATORY CLEAN SOIL SAMPLE: A homogenous, representative soil sample taken at the excavated surface of any pit or production facility containment area in which the pre-closure soil analysis provided by LDNR did not meet LAC 43:XIX.311 and 313 closure requirements.
- 6. ORPHAN WELL: A well which has been orphaned pursuant to the provisions of R.S. 30:80 et seg.
- 7. TANK BATTERY: An area allocated in the general proximity to well sites for the purpose of containing hydrocarbon and produced water storage tanks. It is normally bordered by containment dikes/levees. A tank battery may or may not have existing storage tanks.
- 8. PITS: A natural topographic depression or man made excavation used to hold produced water or other non-hazardous oilfield waste. See LAC 43:XIX.301.
- 9. SITE: The confines established for a specific well or group of wells and associated pits, tank batteries, and facilities.
- 10. SUBCONTRACTOR: Any individual, firm, partnership, corporation, or combination of the two or more firms or corporations acting jointly, that are bound contractually to the contractor to perform portions of this work.
- 11. COMMENCEMENT OF WORK: Physically and actively performing the scope of work contained in the bid document, such as closing a pit or plugging a well. This definition does not include moving equipment on to the location or "visiting" the location.
- 12. FACILITY: The aggregate of vessels, separators, heaters, tanks, treaters, etc. (commonly referred to as production equipment), utilized in the producing and processing of effluents from a well.
- 13. PLUG AND ABANDON: The date the well is cut and capped, or casing is cut at specified depth below mud line.
- 14. BOP TEST: This test is to verify the good working condition of the BOP. The hydraulic closure system on the preventers must be operational at all times. Pressure test to qualify integrity of BOP body, connection to wellhead, and seal of blind or pipe ram elements. A retest is required each time the BOP stack is removed and subsequently reinstalled on the well.

# INFORMATION BIDDERS ARE REQUIRED TO SUBMIT WITH BID PROPOSAL

- 1. This entire bid package.
- 2. Any addendum(s) related to this bid proposal.
- 3. If the procedures in the bid are to be utilized, this must be stated. If procedures are altered or changed, then these procedures must be submitted.
- 4. Contractor shall provide a **project schedule** outlining the following:
  - (a) **Specific procedures** that he will perform in order to carry out the scope of work on the wells.
  - (b) The number of days expected to complete the work on the wells and pits.
  - (c) **Description of workday** hours and work week (ex. Monday thru Friday).
- 5. List of subcontractors. (Section 2.6)
- 6. **List of equipment** to be used on this project. All equipment brought to location shall be pretested and in good working condition and shall be rated to handle work anticipated based on depth and procedures.
- 7. **List of personnel** required to perform the scope of work.
- 8. Completed breakdown of lump sum total worksheet included in this bid document (Section 8).
- 9. Only the successful bidder will be required to submit a **current insurance certificate** at the time the bid is awarded. The certificate shall meet the requirements outlined in **Attachment 'B'** and shall reference the bid proposal number.

# **MINIMUM EQUIPMENT REQUIREMENTS**

The equipment requirements cited in this section shall be only the minimum requirements for the basic equipment packages used in performing the scope of work for the restoration of each of the sites contained in the bid. It remains the contractor's responsibility to include in the bid all other tools and equipment necessary to complete the scope of work.

PLUGGING EQUIPMENT - LAND OPERATIONS - This service is to include the following items of equipment:

- A. Rig Workover rig capable of plugging wells to a depth of 2,200 ft. The rig shall be capable of pulling a minimum load of 80,000 lb with two lines run through the blocks. The rig package shall include a minimum of a four (4) man crew plus tool pusher, power tongs, weight indicator, and all handling tools for 2 3/8" and 1" workstrings.
- B. Hydraulically actuated blowout preventers rated to a minimum 3000 psi working pressure.
- C. Pressure safety valve rated to a minimum 3000 psi working pressure.
- D. Circulating pump capable of pressuring up and circulating to 1000 psi at 3 barrels per minute minimum. All connections in the line from the pump to wellhead shall also be rated to 1000 psi.
- E. 80 barrel steel circulating tank
- F. 2,200' of 1" workstring and 2,800' of 2 3/8" workstring in order to run the cement retainers.

# **SCOPE OF WORK**

A. Well Name Serial Number Operator of Record

W B Williams #2 143817 Bagby Operating Co., Inc. OC B178

General Description

Location: Lat. - 32 deg. 40 min. 46.5 sec. Long. - 91 deg. 55 min. 3.2 sec.

Section 35, T20N, R05E Monroe Field, Morehouse Parish

Casing configuration: 7" 15.5 #/ft 0' - 212' w/ 100 sx

2 7/8" 6.5 #/ft 0' - 2245' w/ 100 sx

Latest borehole information:

Drilled TD: 2260' Tubing: 3/4'' (0' - 2240')?

PBTD: Packer: Unknown USDW: 1020' Perfs: 2244' – 2260'

Plugging and Abandonment Procedure

All cement plugs to be Class A, having a minimum density of 15.6 pounds per gallon, and contain an accelerator.

1. Move in, rig up, and kill well. Install and pressure test blowout preventers.

2. POOH with tubing, packer, or hanger if present.

3. Fish with appropriate fishing tools to recover remaining tubing from well (allow for 4 hours fishing time).

4. Pick up work string. GIH with gauge bit and clean out production casing to 2100'. Circulate well clean. POOH.

5. Set a CIBP at 2100'. Pressure test casing to 300 PSI.

6. GIH with tubing to CIBP. Circulate and fill 2 7/8" casing with cement from top of CIBP to 1130'.

7. Perforate production casing with a thru-tubing perforating gun (2'-4 shots per foot--180° phasing) at 1120'. Establish injection into perforations.

8. Pump and squeeze 50 sacks cement into perforations and fill 2 7/8" casing to surface with cement.

9. Circulate with small tubing a minimum 100' surface plug between all casing strings, leaving annulus full of cement to the surface.

10. Cut all casing a minimum of five feet (5') below ground level and weld a ½ inch steel plate on the top of each casing string. Weld or stencil serial number and date on top plate.

11. Remove and dispose of all equipment, material and debris associated with the past operation of this well.

12. Restore well site along with access routes.

B. Well Name Serial Number Operator of Record

W B Williams #3 143818 Bagby Operating Co., Inc. OC 4201

General Description

Location: Lat. - 32 deg. 40 min. 54 sec. Long. - 91 deg. 54 min. 48 sec.

Section 36, T20N, R05E Monroe Field, Morehouse Parish

Casing configuration: 7" 15.5 #/ft 0' - 209' w/ 100 sx 2 7/8" 6.5 #/ft 0' - 2245' w/ 100 sx

Latest borehole information:

Drilled TD: 2270' Tubing: 3/4" (0 - 2240')
PBTD: 2270' Packer: Unknown
USDW: 1020' Perfs: 2245' – 2270'

#### Plugging and Abandonment Procedure

All cement plugs to be Class A, having a minimum density of 15.6 pounds per gallon, and contain an accelerator.

1. Move in, rig up, and kill well. Install and pressure test blowout preventers.

2. POOH with tubing, packer, or hanger if present.

- 3. Fish with appropriate fishing tools to recover remaining tubing from well (allow for 4 hours fishing time).
- 4. Pick up work string. GIH with gauge bit and clean out production casing to 2000'. Circulate well clean. POOH.
- 5. Set a CIBP at 2000'. Pressure test casing to 300 PSI.
- 6. GIH with tubing to CIBP. Circulate and fill 2 7/8" casing with cement from top of CIBP to 1130'.
- 7. Perforate production casing with a thru-tubing perforating gun (2'-4 shots per foot--180° phasing) at 1120'. Establish injection into perforations.
- 8. Pump and squeeze 50 sacks cement into perforations and fill 2 7/8" casing to surface with cement.
- 9. Circulate with small tubing a minimum 100' surface plug between all casing strings, leaving annulus full of cement to the surface.
- 10. Cut all casing a minimum of five feet (5') below ground level and weld a ½ inch steel plate on the top of each casing string. Weld or stencil serial number and date on top plate.
- 11. Remove and dispose of all equipment, material and debris associated with the past operation of this well.
- 12. Restore well site along with access routes.

C. <u>Well Name</u> <u>Serial Number</u> <u>Operator of Record</u>

Weaver #1 146021 William E Weaver OC W054

General Description

Location: Lat. - 32 deg. 40 min. 17.2 sec. Long. - 91 deg. 55 min. 7.0 sec.

Section 35, T20N, R05E Monroe Field, Morehouse Parish

Casing configuration: 7" 23 #/ft 0' - 107' w/ 100 sx

2 3/8" 4.5 #/ft 0' - 2279' w/ 125 sx

Latest borehole information:

Drilled TD: 2280' Tubing: 3/4" (0' – 2248')
PBTD: 2274' Packer: unknown

USDW: 1020' Perfs: 2251' – 2265'

# Plugging and Abandonment Procedure

All cement plugs to be Class A, having a minimum density of 15.6 pounds per gallon, and contain an accelerator.

1. Move in, rig up, and kill well. Install and pressure test blowout preventers.

2. POOH with tubing, packer, or hanger if present.

3. Fish with appropriate fishing tools to recover remaining tubing from well (allow for 4 hours fishing time).

4. Pick up work string. GIH with gauge bit and clean out production casing to 2000'. Circulate well clean. POOH.

5. Set a CIBP at 2000'. Pressure test casing to 300 PSI.

6. GIH with tubing to CIBP. Circulate and fill 2 3/8" casing with cement from top of CIBP to 1130'.

7. Perforate production casing with a thru-tubing perforating gun (2'-4 shots per foot--180° phasing) at 1120'. Establish injection into perforations.

8. Pump and squeeze 50 sacks cement into perforations and fill 2 3/8" casing to surface with cement.

9. Circulate with small tubing a minimum of 100' surface cement plug between all casing strings, leaving annulus full of cement to the surface.

10. Cut all casing a minimum of five feet (5') below ground level and weld a ½ inch steel plate on the top of each casing string. Weld or stencil serial number and date on top plate.

11. Remove and dispose of all equipment, material and debris associated with the past operation of this well.

12. Restore well site along with access routes.

D. <u>Well Name</u> <u>Serial Number</u> Operator of Record

Ann B Padgett Et Al #1 156068 Talleco Oil & Gas, Inc. OC T047

General Description

Location: Lat. - 32 deg. 40 min. 13 sec. Long. - 91 deg. 54 min. 2.9 sec.

Section 31, T20N, R06E Monroe Field, Morehouse Parish

Casing configuration: 8 5/8" 20 #/ft 0' - 200' w/ 200 sx

3 1/2" 7.7 #/ft 0' - 2336' w/ 200 sx

Latest borehole information:

Drilled TD: 2385' Tubing: 1" (0' – 2190')

PBTD: 2336' Packer:

USDW: 1040' Perfs: 2203 – 2208'

# Plugging and Abandonment Procedure

All cement plugs to be Class A, having a minimum density of 15.6 pounds per gallon, and contain an accelerator.

- 1. Move in, rig up, and kill well. Install and pressure test blowout preventers.
- 2. POOH with tubing, packer, or hanger if present.
- 3. Fish with appropriate fishing tools to recover remaining tubing from well (allow for 4 hours fishing time).
- 4. Pick up work string. GIH with gauge bit and clean out production casing to 2000'. Circulate well clean. POOH.
- 5. Set a CIBP at 2000'. Pressure test casing to 300 PSI.
- 6. GIH with tubing to CIBP. Spot a 20 sack cement plug on top of CIBP.
- 7. Circulate well with a minimum 9.0 ppg corrosion inhibited fluid (and leave between all cement plugs).
- 8. Perforate production casing with a thru-tubing perforating gun (2'-4 shots per foot--180° phasing) at 1140'. Establish injection into perforations.
- 9. Set a cement retainer within 30' of perforations at 1140'.
- 10. Sting into retainer and pump 50 sacks of cement below retainer into perforations.
- 11. Remove stinger from retainer and spot 15 sack cement plug on top of retainer.
- 12. Spot a balanced 150' surface cement plug inside production casing.
- 13. Circulate with small tubing a minimum 100' surface plug between all casing strings, leaving annulus full of cement to the surface.
- 14. Cut all casing a minimum of five feet (5') below ground level and weld a ½ inch steel plate on the top of each casing string. Weld or stencil serial number and date on top plate.
- 15. Remove and dispose of all equipment, material and debris associated with the past operation of this well.
- 16. Restore well site along with access routes.

E. <u>Well Name</u> <u>Serial Number</u> <u>Operator of Record</u>

Mary D Pugh #1 156070 Energy 2000 NGC Inc. OC E106

**General Description** 

Location: Lat. - 32 deg. 40 min. 29.4 sec. Long. - 91 deg. 54 min. 15 sec.

Section 36, T20N, R05E Monroe Field, Morehouse Parish

Casing configuration: 8 5/8" 20 #/ft 0' - 205' w/ 200 sx

3 1/2" 6.5 #/ft 0' - 2265' w/ 200 sx

Latest borehole information:

Drilled TD: 2282' Tubing: 1" (0' – 2190')

PBTD: 2200' Packer: None

USDW: 1020' Perfs: 2208 – 2213'

# Plugging and Abandonment Procedure

All cement plugs to be Class A, having a minimum density of 15.6 pounds per gallon, and contain an accelerator.

1. Move in, rig up, and kill well. Install and pressure test blowout preventers.

2. POOH with tubing, packer, or hanger if present.

3. Fish with appropriate fishing tools to recover remaining tubing from well (allow for 4 hours fishing time).

4. Pick up work string. GIH with gauge bit and clean out production casing to 2000'. Circulate well clean. POOH.

5. Set a CIBP at 2000'. Pressure test casing to 300 PSI.

6. GIH with tubing to CIBP. Spot a 20 sack cement plug on top of CIBP.

7. Circulate well with a minimum 9.0 ppg corrosion inhibited fluid (and leave between all cement plugs).

8. Perforate production casing with a thru-tubing perforating gun (2'-4 shots per foot--180° phasing) at 1120'. Establish injection into perforations.

9. Set a cement retainer within 30' of perforations at 1120'.

10. Sting into retainer and pump 50 sacks of cement below retainer into perforations.

11. Remove stinger from retainer and spot 15 sack cement plug on top of retainer.

12. Spot a balanced 150' surface cement plug inside production casing.

13. Circulate with small tubing a minimum 100' surface plug between all casing strings, leaving annulus full of cement to the surface.

14. Cut all casing a minimum of five feet (5') below ground level and weld a ½ inch steel plate on the top of each casing string. Weld or stencil serial number and date on top plate.

15. Remove and dispose of all equipment, material and debris associated with the past operation of this well.

16. Restore well site along with access routes.

F. Well Name Serial Number Operator of Record

Mary D Pugh #3 156240 Energy 2000 NGC Inc. OC E106

General Description

Location: Lat. - 32 deg. 40 min. 21.2 sec. Long. - 91 deg. 54 min. 15.6 sec.

Section 36, T20N, R05E Monroe Field, Morehouse Parish

Casing configuration: 8 5/8" 20 #/ft 0' - 198' w/ 125 sx

3 1/2" 7.7 #/ft 0' - 2253' w/ 200 sx

Latest borehole information:

Drilled TD: 2258' Tubing: 1" (0' – 2165')

PBTD: 2254' Packer: None

USDW: 1020' Perfs: 2180 – 2187'

# Plugging and Abandonment Procedure

All cement plugs to be Class A, having a minimum density of 15.6 pounds per gallon, and contain an accelerator.

1. Move in, rig up, and kill well. Install and pressure test blowout preventers.

2. POOH with tubing, packer, or hanger if present.

- 3. Fish with appropriate fishing tools to recover remaining tubing from well (allow for 4 hours fishing time).
- 4. Pick up work string. GIH with gauge bit and clean out production casing to 2000'. Circulate well clean. POOH.
- 5. Set a CIBP at 2000'. Pressure test casing to 300 PSI.
- 6. GIH with tubing to CIBP. Spot a 20 sack cement plug on top of CIBP.
- 7. Circulate well with a minimum 9.0 ppg corrosion inhibited fluid (and leave between all cement plugs).
- 8. Perforate production casing with a thru-tubing perforating gun (2'-4 shots per foot--180° phasing) at 1120'. Establish injection into perforations.
- 9. Set a cement retainer within 30' of perforations at 1120'.
- 10. Sting into retainer and pump 50 sacks of cement below retainer into perforations.
- 11. Remove stinger from retainer and spot 15 sack cement plug on top of retainer.
- 12. Spot a balanced 150' surface cement plug inside production casing.
- 13. Circulate with small tubing a minimum 100' surface plug between all casing strings, leaving annulus full of cement to the surface.
- 14. Cut all casing a minimum of five feet (5') below ground level and weld a ½ inch steel plate on the top of each casing string. Weld or stencil serial number and date on top plate.
- 15. Remove and dispose of all equipment, material and debris associated with the past operation of this well.
- 16. Restore well site along with access routes

# G. Well Name

# Serial Number

# **Operator of Record**

Ann B Padgett Et Al A #4

157775

Talleco Oil & Gas, Inc. OC T047

General Description

Location: Lat. - 32 deg. 40 min. 32.5 sec.

Section 31, T20N, R06E

Long. - 91 deg. 54 min. 7.1 sec. Monroe Field, Morehouse Parish

Casing configuration:

8 5/8" 20 #/ft 0' - 262' w/ 150 sx

3 1/2" 6.5 #/ft

0' - 2290' w/ 175 sx

Latest borehole information:

Drilled TD: 2291'

Tubing:

1'' (0' - 2190')

PBTD:

2270'

Packer:

Unknown

USDW:

870'

Perfs:

2204 - 2209

**NOTE:** Casing sheared off at ground level

# Plugging and Abandonment Procedure

All cement plugs to be Class A, having a minimum density of 15.6 pounds per gallon, and contain an accelerator.

- 1. Move in, rig up, and kill well. Install and pressure test blowout preventers.
- POOH with tubing, packer, or hanger if present. 2.
- 3. Fish with appropriate fishing tools to recover remaining tubing from well (allow for 4 hours fishing time).
- 4. Pick up work string. GIH with gauge bit and clean out production casing to 2000'. Circulate well clean. POOH.
- 5. Set a CIBP at 2000'. Pressure test casing to 300 PSI.
- GIH with tubing to CIBP. Spot a 20 sack cement plug on top of CIBP. 6.
- 7. Circulate well with a minimum 9.0 ppg corrosion inhibited fluid (and leave between all cement plugs).
- Perforate production casing with a thru-tubing perforating gun (2'-4 shots per foot--180° phasing) at 970'. 8. Establish injection into perforations.
- Set a cement retainer within 30' of perforations at 970'. 9.
- Sting into retainer and pump 50 sacks of cement below retainer into perforations. 10.
- Remove stinger from retainer and spot 15 sack cement plug on top of retainer. 11.
- Spot a balanced 150' surface cement plug inside production casing. 12.
- Circulate with small tubing a minimum 100' surface plug between all casing strings, leaving annulus full of 13. cement to the surface.
- 14. Cut all casing a minimum of five feet (5') below ground level and weld a ½ inch steel plate on the top of each casing string. Weld or stencil serial number and date on top plate.
- Remove and dispose of all equipment, material and debris associated with the past operation of this well. 15.
- Restore well site along with access routes.

H. Well Name Serial Number Operator of Record

Harrell SU913;K E Gewin Et Al #1 164982 Energy 2000 NGC Inc. OC E106

General Description

Location: Lat. - 32 deg. 36 min. 47.7 sec.

Section 24, T19N, R05E

Long. - 91 deg. 54 min. 44.5 sec.

Monroe Field, Morehouse Parish

Casing configuration:

8 5/8" 20 #/ft

0' - 250' w/ 350 sx

4 1/2" 9.5 #/ft 0' - 2764' w/ 275 sx

Latest borehole information:

Drilled TD: 2769'

Tubing:

1'' (0' - 2279')

PBTD:

2670'

Packer:

None

USDW: 1570'

Perfs:

2288' - 2291' and 2270' - 2272'

# Plugging and Abandonment Procedure

All cement plugs to be Class A, having a minimum density of 15.6 pounds per gallon, and contain an accelerator.

- 1. Move in, rig up, and kill well. Install and pressure test blowout preventers.
- 2. POOH with tubing, packer, or hanger if present.
- 3. Fish with appropriate fishing tools to recover remaining tubing from well (allow for 4 hours fishing time).
- 4. Pick up work string. GIH with gauge bit and clean out production casing to 2000'. Circulate well clean. POOH.
- 5. Set a CIBP at 2000'. Pressure test casing to 300 PSI.
- 6. GIH with tubing to CIBP. Spot a 20 sack cement plug on top of CIBP.
- 7. Circulate well with a minimum 9.0 ppg corrosion inhibited fluid (and leave between all cement plugs).
- 8. Perforate production casing with a thru-tubing perforating gun (2'-4 shots per foot--180° phasing) at 1670'. Establish injection into perforations.
- 9. Set a cement retainer within 30' of perforations at 1670'.
- 10. Sting into retainer and pump 50 sacks of cement below retainer into perforations.
- 11. Remove stinger from retainer and spot 15 sacks of cement below retainer into perforations.
- 12. Spot a balanced 150' surface cement plug inside production casing.
- 13. Circulate with small tubing a minimum 100' surface plug between all casing strings, leaving annulus full of cement to the surface.
- 14. Cut all casing a minimum of five feet (5') below ground level and weld a ½ inch steel plate on the top of each casing string. Weld or stencil serial number and date on top plate.
- 15. Remove and dispose of all equipment, material and debris associated with the past operation of this well.
- 16. Restore well site along with access routes.

# I. Well Name Serial Number Operator of Record

#### Annona RA SUN; K E Gewin Et Al #2 165722

Energy 2000 NGC Inc. OC E106

General Description

Location: Lat. - 32 deg. 36 min. 47.5 sec.

Long. - 91 deg. 54 min. 29 sec.

Section 24, T19N, R05E

Monroe Field, Morehouse Parish

Casing configuration:

8 5/8" 20 #/ft

0' - 160' w/ 150 sx

4 1/2" 9.5 #/ft

0' - 2482' w/ 200 sx

Latest borehole information:

Drilled TD: 2499'

Tubing:

1'' (0' - 2215')

PBTD: 2473'

Packer:

None

USDW: 1255'

Perfs:

2226' - 2230'

#### Plugging and Abandonment Procedure

All cement plugs to be Class A, having a minimum density of 15.6 pounds per gallon, and contain an accelerator.

- 1. Move in, rig up, and kill well. Install and pressure test blowout preventers.
- 2. POOH with tubing, packer, or hanger if present.
- 3. Fish with appropriate fishing tools to recover remaining tubing from well (allow for 4 hours fishing time).
- 4. Pick up work string. GIH with gauge bit and clean out production casing to 2000'. Circulate well clean. POOH.
- 5. Set a CIBP at 2000'. Pressure test casing to 300 PSI.
- 6. GIH with tubing to CIBP. Spot a 20 sack cement plug on top of CIBP.
- 7. Circulate well with a minimum 9.0 ppg corrosion inhibited fluid (and leave between all cement plugs).
- 8. Spot a balanced 100' cement plug inside production casing from 1150' to 1250'.
- 9. Spot a balanced 150' surface plug inside production casing.
- 10. Circulate with small tubing a minimum of 100' surface cement plug between all casing strings, leaving annulus full of cement to the surface.
- 11. Cut all casing a minimum of five feet (5') below ground level and weld a ½ inch steel plate on the top of each casing string. Weld or stencil serial number and date on top plate.
- 12. Remove and dispose of all equipment, material and debris associated with the past operation of this well.
- 13. Restore well site along with access routes.

J. Well Name Serial Number Operator of Record

Harrell SU914; Ambrose Meeks #1 172262 Energy 2000 NGC Inc. OC E106

**General Description** 

Location: Lat. - 32 deg. 36 min. 57.5 sec. Long. - 91 deg. 54 min. 33.5 sec.

Section 24, T19N, R05E Monroe Field, Morehouse Parish

Casing configuration: 8 5/8" 20 #/ft 0' - 167' w/ 140 sx

4 1/2" 9.5 #/ft 0' - 2489' w/ 275 sx

Latest borehole information:

 Drilled TD: 2499'
 Tubing:
 1" (0' – 2265')

 PBTD: 2494'
 Packer:
 Unknown

 USDW: 970'
 Perfs: 2275' – 2277'

# Plugging and Abandonment Procedure

All cement plugs to be Class A, having a minimum density of 15.6 pounds per gallon, and contain an accelerator.

1. Move in, rig up, and kill well. Install and pressure test blowout preventers.

2. POOH with tubing, packer, or hanger if present.

3. Fish with appropriate fishing tools to recover remaining tubing from well (allow for 4 hours fishing time).

- 4. Pick up work string. GIH with gauge bit and clean out production casing to 2000'. Circulate well clean. POOH.
- 5. Set a CIBP at 2000'. Pressure test casing to 300 PSI.
- 6. GIH with tubing to CIBP. Spot a 20 sack cement plug on top of CIBP.
- 7. Circulate well with a minimum 9.0 ppg corrosion inhibited fluid (and leave between all cement plugs).
- 8. Spot a balanced 100' cement plug inside production casing from 1200' to 1300'.
- 9. Spot a balanced 150' surface cement plug inside production casing.
- 10. Circulate with small tubing a minimum 100' surface plug between all casing strings, leaving annulus full of cement to the surface.
- 11. Cut all casing a minimum of five feet (5') below ground level and weld a ½ inch steel plate on the top of each casing string. Weld or stencil serial number and date on top plate.
- 12. Remove and dispose of all equipment, material and debris associated with the past operation of this well.
- 13. Restore well site along with access routes.

K. Well Name Serial Number Operator of Record

W B Williams #4 173150 Bagby Operating Co. OC B178

General Description

Location: Lat. - 32 deg. 40 min. 48.9 sec. Long. - 91 deg. 54 min. 37.3 sec.

Section 36, T20N, R05E Monroe Field, Morehouse Parish

Casing configuration: 8 5/8" 20 #/ft 0' - 177' w/ 125 sx

3 1/2" 7.58 #/ft 0' - 2340' w/ 150 sx

Latest borehole information:

Drilled TD: 2360' Tubing: 1 1/4" (0' – 2228')

PBTD: 2340' Packer: none

USDW: 1020' Perfs: 2238' – 2241'

# Plugging and Abandonment Procedure

All cement plugs to be Class A, having a minimum density of 15.6 pounds per gallon, and contain an accelerator.

1. Move in, rig up, and kill well. Install and pressure test blowout preventers.

2. POOH with tubing, packer, or hanger if present.

- 3. Fish with appropriate fishing tools to recover remaining tubing from well (allow for 4 hours fishing time).
- 4. Pick up work string. GIH with gauge bit and clean out production casing to 2100'. Circulate well clean. POOH.
- 5. Set a CIBP at 2100'. Pressure test casing to 300 PSI.
- 6. GIH with tubing to CIBP. Spot a 20 sack cement plug on top of CIBP.
- 7. Circulate well full of minimum 9.0 ppg corrosion inhibited fluid (and leave between all cement plugs).
- 8. Perforate production casing with a thru-tubing perforating gun (2'-4 shots per foot--180° phasing) at 1120'. Establish injection into perforations.
- 9. Set a cement retainer within 30' of perforations at 1120'.
- 10. Sting into retainer and pump 50 sacks of cement below retainer into perforations.
- 11. Remove stinger from retainer and spot 15 sack cement plug on top of retainer.
- 12. Spot a balanced 150' surface cement plug inside production casing.
- 13. Circulate with small tubing a minimum 100' surface plug between all casing strings, leaving annulus full of cement to the surface.
- 14. Cut all casing a minimum of five feet (5') below ground level and weld a ½ inch steel plate on the top of each casing string. Weld or stencil serial number and date on top plate.
- 15. Remove and dispose of all equipment, material and debris associated with the past operation of this well.
- 16. Restore well site along with access routes

# L. Well Name Serial Number Operator of Record

Annona RA SUA:Robert Hodges #1 177634 Energy 20

Energy 2000 NGC Inc. OC E106

General Description

Location: Lat. - 32 deg. 36 min. 39.9 sec.

Section 25, T19N, R05E

Long. - 91 deg. 54 min. 24.8 sec.

Monroe Field, Morehouse Parish

Casing configuration:

8 5/8" 20 #/ft

0' - 179' w/ 200 sx

4 1/2" 9.5 #/ft

0' - 2470' w/ 200 sx

Latest borehole information:

Drilled TD: 2490'

Tubing:

unknown

PBTD: 2

2468'

Packer:

unknown

USDW: 1020' Perfs:

2267.5' - 2271.5'

# Plugging and Abandonment Procedure

All cement plugs to be Class A, having a minimum density of 15.6 pounds per gallon, and contain an accelerator.

- 1. Move in, rig up, and kill well. Install and pressure test blowout preventers.
- 2. POOH with tubing, packer, or hanger if present.
- 3. Fish with appropriate fishing tools to recover remaining tubing from well (allow for 4 hours fishing time).
- 4. Pick up work string. GIH with gauge bit and clean out production casing to 2100'. Circulate well clean. POOH.
- 5. Set a CIBP at 2100'. Pressure test casing to 300 PSI.
- 6. GIH with tubing to CIBP. Spot a 20 sack cement plug on top of CIBP.
- 7. Circulate well full of minimum 9.0 ppg corrosion inhibited fluid (and leave between all cement plugs).
- 8. Perforate production casing with a thru-tubing perforating gun (2'-4 shots per foot--180° phasing) at 1120'. Establish injection into perforations.
- 9. Set a cement retainer within 30' of perforations at 1120'.
- 10. Sting into retainer and pump 50 sacks of cement below retainer into perforations.
- 11. Remove stinger from retainer and spot 15 sack cement plug on top of retainer.
- Spot a balanced 150' surface cement plug inside production casing.
- 13. Circulate with small tubing a minimum 100' surface plug between all casing strings, leaving annulus full of cement to the surface.
- 14. Cut all casing a minimum of five feet (5') below ground level and weld a ½ inch steel plate on the top of each casing string. Weld or stencil serial number and date on top plate.
- 15. Remove and dispose of all equipment, material and debris associated with the past operation of this well.
- 16. Restore well site along with access routes.

M. Well Name Serial Number Operator of Record

Chapman Heirs #1 179983 Marjo, Inc. OC 2917

General Description

Location: Lat. - 32 deg. 23 min. 27.8 sec. Long. - 91 deg. 40 min. 39.7 sec.

Section 08, T16N, R08E Big Creek Field, Richland Parish

Casing configuration: 8 5/8" 24 #/ft 0' - 300' w/ 200 sx

4 1/2" 9.5 #/ft 0' - 3093' w/ 200 sx

Latest borehole information:

Drilled TD: 3100' Tubing: 2" (0' – 2970')

PBTD: 2990' Packer: None

USDW: 1220' Perfs: 2972' – 2974'

# Plugging and Abandonment Procedure

All cement plugs to be Class A, having a minimum density of 15.6 pounds per gallon, and contain an accelerator.

- 1. Move in, rig up, and kill well. Install and pressure test blowout preventers.
- 2. POOH with tubing, packer, or hanger if present.
- 3. Fish with appropriate fishing tools to recover remaining tubing from well (allow for 4 hours fishing time).
- 4. Pick up work string. GIH with gauge bit and clean out production casing to 2700'. Circulate well clean. POOH.
- 5. Set a CIBP at 2700'. Pressure test casing to 300 PSI.
- 6. GIH with tubing to CIBP. Spot a 20 sack cement plug on top of CIBP.
- 7. Circulate well full of minimum 9.0 ppg corrosion inhibited fluid (and leave between all cement plugs).
- 8. Perforate production casing with a thru-tubing perforating gun (2'-4 shots per foot--180° phasing) at 1320'. Establish injection into perforations.
- 9. Set a cement retainer within 30' of perforations at 1320'.
- 10. Sting into retainer and pump 50 sacks of cement below retainer into perforations.
- 11. Remove stinger from retainer and spot 15 sack cement plug on top of retainer.
- 12. Spot a balanced 150' surface cement plug inside production casing.
- 13. Circulate with small tubing a minimum 100' surface plug between all casing strings, leaving annulus full of cement to the surface.
- 14. Cut all casing a minimum of five feet (5') below ground level and weld a ½ inch steel plate on the top of each casing string. Weld or stencil serial number and date on top plate.
- 15. Remove and dispose of all equipment, material and debris associated with the past operation of this well.
- 16. Restore well site along with access routes.

N. Well Name Serial Number Operator of Record

VUA; Weaver #1 191604 Energy 2000 NGC Inc. OC E106

General Description

Location: Lat. - 32 deg. 40 min. 18.9 sec. Long. - 91 deg. 55 min. 7.2 sec.

Section 35, T20N, R05E Monroe Field, Morehouse Parish

Casing configuration: 8 5/8" 20 #/ft 0' - 165' w/ 130 sx

4 1/2" 9.5 #/ft 0' - 2484' w/ 200 sx

Latest borehole information:

Drilled TD: 2488' Tubing: 1" (0' – 2300')
PBTD: 2444' Packer: Unknown
USDW: 1020' Perfs: 2310' – 2312'

Plugging and Abandonment Procedure

All cement plugs to be Class A, having a minimum density of 15.6 pounds per gallon, and contain an accelerator.

1. Move in, rig up, and kill well. Install and pressure test blowout preventers.

2. POOH with tubing, packer, or hanger if present.

- 3. Fish with appropriate fishing tools to recover remaining tubing from well (allow for 4 hours fishing time).
- 4. Pick up work string. GIH with gauge bit and clean out production casing to 2100'. Circulate well clean. POOH.
- 5. Set a CIBP at 2100'. Pressure test casing to 300 PSI.
- 6. GIH with tubing to CIBP. Spot a 20 sack cement plug on top of CIBP.
- 7. Circulate well full of minimum 9.0 ppg corrosion inhibited fluid (and leave between all cement plugs).
- 8. Perforate production casing with a thru-tubing perforating gun (2'-4 shots per foot--180° phasing) at 1120'. Establish injection into perforations.
- 9. Set a cement retainer within 30' of perforations at 1120'.
- 10. Sting into retainer and pump 50 sacks of cement below retainer into perforations.
- 11. Remove stinger from retainer and spot 15 sack cement plug on top of retainer.
- 12. Spot a balanced 150' surface cement plug inside production casing.
- 13. Circulate with small tubing a minimum 100' surface plug between all casing strings, leaving annulus full of cement to the surface.
- 14. Cut all casing a minimum of five feet (5') below ground level and weld a ½ inch steel plate on the top of each casing string. Weld or stencil serial number and date on top plate.
- 15. Remove and dispose of all equipment, material and debris associated with the past operation of this well.
- 16. Restore well site along with access routes.

O. Well Name Serial Number Operator of Record

Harrell SU685; Williams #1 195321 Energy 2000 NGC Inc. OC E106

**General Description** 

Location: Lat. - 32 deg. 40 min. 36.3 sec. Long. - 91 deg. 55 min. 15.9 sec.

Section 35, T20N, R05E Monroe Field, Morehouse Parish

Casing configuration: 8 5/8" 20 #/ft 0' - 160' w/ 125 sx

4 1/2" 9.5 #/ft 0' - 2690' w/ 250 sx

Latest borehole information:

Drilled TD: 2713' Tubing: 1" (0' – 2321')
PBTD: 2654' Packer: Unknown

USDW: 1020' Perfs: 2331' – 2335'

# Plugging and Abandonment Procedure

All cement plugs to be Class A, having a minimum density of 15.6 pounds per gallon, and contain an accelerator.

1. Move in, rig up, and kill well. Install and pressure test blowout preventers.

2. POOH with tubing, packer, or hanger if present.

3. Fish with appropriate fishing tools to recover remaining tubing from well (allow for 4 hours fishing time).

- 4. Pick up work string. GIH with gauge bit and clean out production casing to 2100'. Circulate well clean. POOH.
- 5. Set a CIBP at 2100'. Pressure test casing to 300 PSI.
- 6. GIH with tubing to CIBP. Spot a 20 sack cement plug on top of CIBP.
- 7. Circulate well with a minimum 9.0 ppg corrosion inhibited fluid (and leave between all cement plugs).
- 8. Perforate production casing with a thru-tubing perforating gun (2'-4 shots per foot--180° phasing) at 1120'. Establish injection into perforations.
- 9. Set a cement retainer within 30' of perforations at 1120'.
- 10. Sting into retainer and pump 50 sacks of cement below retainer into perforations.
- 11. Remove stinger from retainer and spot 15 sack cement plug on top of retainer.
- 12. Spot a balanced 150' surface cement plug inside production casing.
- 13. Circulate with small tubing a minimum 100' surface plug between all casing strings, leaving annulus full of cement to the surface.
- 14. Cut all casing a minimum of five feet (5') below ground level and weld a ½ inch steel plate on the top of each casing string. Weld or stencil serial number and date on top plate.
- 15. Remove and dispose of all equipment, material and debris associated with the past operation of this well.
- 16. Restore well site along with access routes.

P. <u>Well Name</u> <u>Serial Number</u> <u>Operator of Record</u>

Griffin #4 198817 Energy 2000 NGC Inc. OC E106

**General Description** 

Location: Lat. - 32 deg. 40 min. 0 sec. Long. - 91 deg. 54 min. 49.3 sec.

Section 2, T19N, R05E Monroe Field, Morehouse Parish

Casing configuration: 8 5/8" 20 #/ft 0' - 160' w/ 150 sx

4 1/2" 9.5 #/ft 0' - 2417' w/ 200 sx

Latest borehole information:

Drilled TD: 2434' Tubing: 1" (0' – 2280')

PBTD: 2417' Packer: None

USDW: 940' Perfs: 2290' – 2295'

**NOTE**: Tubing is rusted off.

# Plugging and Abandonment Procedure

All cement plugs to be Class A, having a minimum density of 15.6 pounds per gallon, and contain an accelerator.

- 1. Move in, rig up, and kill well. Install and pressure test blowout preventers.
- 2. POOH with tubing, packer, or hanger if present.
- 3. Fish with appropriate fishing tools to recover remaining tubing from well (allow for 4 hours fishing time).
- 4. Pick up work string. GIH with gauge bit and clean out production casing to 2000'. Circulate well clean. POOH.
- 5. Set a CIBP at 2000'. Pressure test casing to 300 PSI.
- 6. GIH with tubing to CIBP. Spot a 20 sack cement plug on top of CIBP.
- 7. Circulate well with a minimum 9.0 ppg corrosion inhibited fluid (and leave between all cement plugs).
- 8. Perforate production casing with a thru-tubing perforating gun (2'-4 shots per foot--180° phasing) at 1040'. Establish injection into perforations.
- 9. Set a cement retainer within 30' of perforations at 1040'.
- 10. Sting into retainer and pump 50 sacks of cement below retainer into perforations.
- 11. Remove stinger from retainer and spot 15 sack cement plug on top of retainer.
- 12. Spot a balanced 150' surface cement plug inside production casing.
- 13. Circulate with small tubing a minimum 100' surface plug between all casing strings, leaving annulus full of cement to the surface.
- 14. Cut all casing a minimum of five feet (5') below ground level and weld a ½ inch steel plate on the top of each casing string. Weld or stencil serial number and date on top plate.
- 15. Remove and dispose of all equipment, material and debris associated with the past operation of this well.
- 16. Restore well site along with access routes.

Q. Well Name Serial Number Operator of Record

Griffin #5 204869 Energy 2000 NGC Inc. OC E106

**General Description** 

Location: Lat. - 32 deg. 39 min. 57.8 sec. Long. - 91 deg. 54 min. 53.9 sec.

Section 1, T19N, R05E Monroe Field, Morehouse Parish

Casing configuration: 8 5/8" 20 #/ft 0' - 167' w/ 150 sx 4 1/2" 9.5 #/ft 0' - 2486' w/ 175 sx

Latest borehole information:

Drilled TD: 2497'
PBTD: 2486'
USDW: 940'
Tubing: 1" Unknown
Unknown
Unknown
Unknown

Plugging and Abandonment Procedure

All cement plugs to be Class A, having a minimum density of 15.6 pounds per gallon, and contain an accelerator.

1. Move in, rig up, and kill well. Install and pressure test blowout preventers.

2. POOH with tubing, packer, or hanger if present.

3. Fish with appropriate fishing tools to recover remaining tubing from well (allow for 4 hours fishing time).

4. Pick up work string. GIH with gauge bit and clean out production casing to 2000'. Circulate well clean. POOH.

5. Set a CIBP at 2000'. Pressure test casing to 300 PSI.

6. GIH with tubing to CIBP. Spot a 20 sack cement plug on top of CIBP.

7. Circulate well with a minimum 9.0 ppg corrosion inhibited fluid (and leave between all cement plugs).

8. Perforate production casing with a thru-tubing perforating gun (2'-4 shots per foot--180° phasing) at 1040'. Establish injection into perforations.

9. Set a cement retainer within 30' of perforations at 1040'.

10. Sting into retainer and pump 50 sacks of cement below retainer into perforations.

11. Remove stinger from retainer and spot 15 sack cement plug on top of retainer.

12. Spot a balanced 150' surface cement plug inside production casing.

13. Circulate with small tubing a minimum 100' surface plug between all casing strings, leaving annulus full of cement to the surface.

14. Cut all casing a minimum of five feet (5') below ground level and weld a ½ inch steel plate on the top of each casing string. Weld or stencil serial number and date on top plate.

15. Remove and dispose of all equipment, material and debris associated with the past operation of this well.

16. Restore well site along with access routes

R. <u>Well Name</u> <u>Serial Number</u> <u>Operator of Record</u>

Chapman Heirs #2 211212 Marjo, Inc. OC 2917

General Description

Location: Lat. - 32 deg. 23 min. 40 sec. Long. - 91 deg. 40 min. 43.4 sec.

Section 5, T16N, R08E Big Creek Field, Richland Parish

Casing configuration: 8 5/8" 20 #/ft 0' - 318' w/ 175 sx

4 1/2" 10.5 #/ft 0' - 2992' w/ 175 sx

Latest borehole information:

Drilled TD: 2999' Tubing: none PBTD: 2992' Packer: none

USDW: 855' Perfs: 2935' – 2937'

# Plugging and Abandonment Procedure

All cement plugs to be Class A, having a minimum density of 15.6 pounds per gallon, and contain an accelerator.

1. Move in, rig up, and kill well. Install and pressure test blowout preventers.

2. POOH with tubing, packer, or hanger if present.

- 3. Fish with appropriate fishing tools to recover remaining tubing from well (allow for 4 hours fishing time).
- 4. Pick up work string. GIH with gauge bit and clean out production casing to 2800'. Circulate well clean. POOH.
- 5. Set a CIBP at 2800'. Pressure test casing to 300 PSI.
- 6. GIH with tubing to CIBP. Spot a 20 sack cement plug on top of CIBP.
- 7. Circulate well with a minimum 9.0 ppg corrosion inhibited fluid (and leave between all cement plugs).
- 8. Perforate production casing with a thru-tubing perforating gun (2'-4 shots per foot--180° phasing) at 955'. Establish injection into perforations.
- 9. Set a cement retainer within 30' of perforations at 955'.
- 10. Sting into retainer and pump 50 sacks of cement below retainer into perforations.
- 11. Remove stinger from retainer and spot 15 sack cement plug on top of retainer.
- 12. Spot a balanced 150' surface cement plug inside production casing.
- 13. Circulate with small tubing a minimum 100' surface plug between all casing strings, leaving annulus full of cement to the surface.
- 14. Cut all casing a minimum of five feet (5') below ground level and weld a ½ inch steel plate on the top of each casing string. Weld or stencil serial number and date on top plate.
- 15. Remove and dispose of all equipment, material and debris associated with the past operation of this well.
- 16. Restore well site along with access routes.

# BREAKDOWN OF LUMP SUM TOTAL

	ITEM DESCRIPTION	COST
Α.	P&A well Serial Number 143817	\$
	Fish (4 hours)	\$
В.	P&A well Serial Number 143818	\$
	Fish (4 hours)	\$
C.	P&A well Serial Number 146021	\$
	Fish (4 hours)	\$
D.	P&A well Serial Number 156068	\$
	Fish (4 hours)	\$
E.	P&A well Serial Number 156070	\$
	Fish (4 hours)	\$
F.	P&A well Serial Number 156240	\$
	Fish (4 hours)	\$
G.	P&A well Serial Number 157775	\$
	Fish (4 hours)	\$
Н.	P&A well Serial Number 164982	\$
	Fish (4 hours)	\$
I.	P&A well Serial Number 165722	\$
	Fish (4 hours)	\$
J.	P&A well Serial Number 172262	\$
	Fish (4 hours)	\$
K.	P&A well Serial Number 173150	\$
	Fish (4 hours)	\$
L.	P&A well Serial Number 177634	\$
	Fish (4 hours)	\$
M.	P&A well Serial Number 179983	\$
	Fish (4 hours)	\$
N.	P&A well Serial Number 191604	\$
	Fish (4 hours)	\$
O.	P&A well Serial Number 195321	\$
	Fish (4 hours)	\$
P.	P&A well Serial Number 198817	\$
	Fish (4 hours)	\$
Q.	P&A well Serial Number 204869	\$
	Fish (4 hours)	\$
R.	P&A well Serial Number 211212	\$
	Fish (4 hours)	\$
	Financial Assurance Charge	<b>©</b>

# **Section 8 Continued**

Other (must separately list and identify any a	dditional costs)		
		\$	
		\$	
Deduct salvage value (Itemized listing must be attached)		\$_()	
	TOTAL *	\$	

Bidder must enter a bid amount on all items. Failure to do so may eliminate your bid from consideration. Partial bids for incomplete Scope of Work are not acceptable.

Bidder must supply the information required on Section 5. Failure to do so may eliminate your bid from consideration.

<sup>\*</sup>Must equal the sum of the above items and must equal the lump sum total indicated on Page 3 of the bid document.

# Attachments

#### **ATTACHMENT "A"**

# FINANCIAL ASSURANCE REQUIREMENTS

The Contractor shall furnish Financial Assurances for one hundred percent (100%) of the amount of the contract for the faithful performance of his contract AND one hundred percent (100%) of the amount of the contract to assure payment for the labor & materials, by one of the following or a combination thereof:

#### PERFORMANCE BOND AND/OR LABOR AND MATERIALS BOND:

The performance bond and/or labor and materials bond shall be secured by a Surety or Insurance Company currently on the United States Department of the Treasury Financial Management Service List of approved bonding companies and in accordance with the restrictions set by them or by an insurance company that is either domiciled in Louisiana or owned by Louisiana residents and is licensed to write surety bonds. In addition, any surety bond written for a public works project shall be written by a surety or insurance company that is currently licensed to do business in the State of Louisiana. R.S. 38:2216 (2) requires that a bond shall be countersigned by a Louisiana licensed agent authorized to represent the Surety Company writing the bond and who is residing in this State.

#### LETTER OF CREDIT:

Letter of credit in sole favor of the Department of Natural Resources in a form prescribed by the Secretary of Assistant Secretary issued by a financial institution acceptable to the Secretary or Assistant Secretary (R.S. 30:92).

# ATTACHMENT "B" INSURANCE REQUIREMENTS CERTIFICATE OF INSURANCE ACT 404: P&A CONTRACTS LAND OPERATIONS

# 1. **GENERAL LIABILITY:**

- A. Minimum limits of \$1,000,000 per occurrence.
- B. BI/PD/Contractual/Products-Completed Operations/OCP.
- C. Additional Insured The State of Louisiana, all State Departments, Agencies, Board and Commissions, its officers, directors, agents, and employees are to be included as additional insured with respect to any work done by the Insured under contract.
- D. Waiver of Subrogation in favor of: The State of Louisiana, all State Departments, Agencies, Board and Commissions, its officers, directors, agents and employees with respect to any work done by the Insured under contract.
- E. Pollution Liability including Clean up.
- F. Underground Resources.
- G. Blowout & Cratering.
- H. Broad Form Property Damage.
- I. XCU Explosion/Collapse/Underground.
- J. No restriction in coverage for use of explosives.

#### 2. WORKERS' COMPENSATION:

- A. Statutory coverage and Employers Liability.
- B. Waiver of Subrogation in favor of: The State of Louisiana, all State Departments, Agencies, Board and Commissions, its officers, directors, agents and employees with respect to any work done by the Insured under contract.
- C. Minimum Employers Liability of \$1,000,000/\$1,000,000/\$1,000,000.
- D. No restriction in coverage for use of explosives.

#### 3. **AUTOMOBILE LIABILITY:**

- A. Minimum limits of \$1,000,000 per occurrence.
- B. Owned/Non Owned/Hired Automobiles.
- C. Additional Insured The State of Louisiana, all State Departments, Agencies, Board and Commissions, its officers, directors, agents and employees are to be included as additional insured with respect to any work done by the Insured under contract.
- D. Waiver of Subrogation in favor of: The State of Louisiana, all State Departments, Agencies, Board and Commissions, its officers, directors, agents and employees with respect to any work done by the Insured under contract.

# 4. IF NOT COVERED BY GENERAL LIABILITY

- A. Pollution Liability including Clean up.
- B. Underground Resources.
- C. Blowout & Cratering.
- D. Broad Form Property Damage.
- E. XCU Explosion/Collapse/Underground.

# **ATTACHMENT "C"**

NORM Survey Results (To be provided at site visit)